No. 1699 12-5-28

Hobbies FRETWORK DESIGN

The ⟶ indicates direction of grain of wood.

JAPANESE TABLE CABINET

— SIZE —
HEIGHT .. 13½ in.
WIDTH .. 6⅝ in.
DEPTH .. 4 in.

Moulding No. 36
4 pieces 3" required.

Moulding No. 24
2 pieces .. 6½ in.
2 „ .. 4 „

BALL FEET No. 14
4 required

KNOB No. 26
4 Required

Front of Plinth. Cut one 3/16 in. thick. Back of Plinth. Cut one to outline only omitting all interior frets.

MOULDING No. 36

OVERLAY. Cut one 1/16 in.

OVERLAYS FOR DOORS & SIDES Cut two of each together 1/16 in. thick

ENDS OF DRAWER. Cut one of each 3/16 in. thick.

GUIDE RUNNER

DETAIL showing how pieces are fixed

RUNNER RUNNER GUIDE Runner GUIDE Runner

Runners & Guides for Drawer. Cut one of each 3/16 in. thick.

NOTE.—The Hobbies Presentation Designs are not given away with back numbers of Hobbies. Additional copies may be had from Hobbies, Ltd.

Overlay C Cut one 3/16 in.

OVERLAY C

UPPER BASE B. Cut one 3/16 in.

MOULDING No. 36

Overlays. Cut two 1/16 in.

HOLE FOR FOOT

DOOR STOPS. Cut two 3/16 in. thick.

SIDES OF PLINTH. Cut one of each 3/16 in. thick.

For prices of Wood and Fittings see current Catalogue, or on application.

HOLE FOR FOOT

BASE A. Cut one 3/16 in. thick. Dotted lines indicate position of upper base B.

www.finescrollsaw.com

FLOOR OF CABINET. Cut one 3/16 in. thick.

BOTTOM TO DRAWER. Cut one 3/16 in. thick.

SCREW • SCREW • SCREW

Dotted lines indicate positions of front, back and sides of cabinet screwed to member B.

B

A

A. TOP OF PLINTH & TOP TO CABINET. Cut two 3/16 in. thick to inner line. B TOP TO CABINET. Cut one to outer line 3/16 in. thick.

ADDRESSES.
All orders by post should be addressed—HOBBIES LIMITED, Dereham, Norfolk. Customers residing in the neighbourhood may obtain Tools, Wood and Fittings by calling at the HOBBIES Supply Stores.
LONDON : 65 New Oxford Street, W.C.
„ 147 Bishopsgate, E.C.
„ 79 Walworth Rd., S.E.
GLASGOW : 326 Argyle Street.
MANCHESTER : 10a Piccadilly.
BIRMINGHAM : 9a High Street.
LEEDS : 10 Queen Victoria Street, Briggate.
SOUTHAMPTON : 25 Bernard St.
BRIGHTON : 68 London Road.
SHEFFIELD : 214 West Street.
TORONTO : 385½ Yonge Street.
And at all HOBBIES Authorised Agents.

SCREW • SCREW • SCREW

SCREW • SCREW • SCREW

SCREW SCREW SCREW SCREW

BACK END FRONT DETAIL OF DRAWER

END

BACK OF DRAWER. Cut one 3/16 in. thick.

END

SIDES OF CABINET. Cut two 3/16 in. thick. Dotted lines indicate positions of overlays and moulding.

Moulding No. 24

DOOR STOP

HINGE No. 5308

FRONT OF CABINET Cut one 3/16 in. thick. Cut to the white lines to form the doors which are hinged as shown.

KNOB No. 26

BACK OF CABINET. Cut one to outline only 3/16 in. thick.

Dotted lines indicate positions of overlays and moulding.

HINGE No. 5308

HINGE No. 5308

HINGE No. 5308

HINGE No. 5308

DOOR STOP

SCREW • FLOOR SCREW • MOULDING No. 24 • SCREW

KNOB No. 26

Cut to this line to form drawer front.

KNOB No. 26

Guide

Runner

Runner

Guide